WIRELESS 150N USB ADAPTER QUICK INSTALL GUIDE

MODEL 524698

ENGLISH
DEUTSCH

INTELLINET
NETWORK SOLUTIONS

INT-524698-QIG_EG-0709-03

WASTE ELECTRICAL & ELECTRONIC EQUIPMENT

Disposal of Electric and Electronic Equipment

(applicable in the European Union and other European countries with separate collection systems)

ENGLISH

This symbol on the product or its packaging indicates that this product shall not be treated as household waste.

Instead, it should be taken to an applicable collection point for the recycling of electrical and electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences to the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. If your equipment contains easily removable batteries or accumulators, dispose of these separately according to your local requirements. The recycling of materials will help to conserve natural resources. For more detailed information about recycling of this product, contact your local city office, your household waste disposal service or the shop where you purchased this product. *In countries outside of the EU:* If you wish to discard this product, contact your local authorities and ask for the correct manner of disposal.

DEUTSCH

Dieses auf dem Produkt oder der Verpackung angebrachte Symbol zeigt an, dass dieses Produkt nicht mit dem Hausmüll entsorgt werden darf. In Übereinstimmung mit der Richtlinie 2002/96/EG des Europäischen Parlamentsund des Rates über Elektro- und Elektronik-Altgeräte (WEEE) darf dieses Elektrogerät nicht im normalen Hausmüll oder dem Gelben Sack entsorgt werden. Wenn Sie dieses Produkt entsorgen möchten, bringen Sie es bitte zur Verkaufsstelle zurück oder zum Recycling-Sammelpunkt Ihrer Gemeinde.

ESPAÑOL

Este símbolo en el producto o su embalaje indica que el producto no debe tratarse como residuo doméstico. De conformidad con la Directiva 2002/96/CE de la UE sobre residuos de aparatos eléctricos y electrónicos (RAEEI), este producto eléctrico no puede desecharse con el resto de residuos no clasificados. Desháguase de este producto devolviéndolo al punta de venta o a un punta de recogida municipal para su reciclaje.

FRANÇAIS

Ce symbole sur le produit ou son emballage signifie que ce produit ne doit pas être traité comme un déchet ménager. Conformément à la Directive 2002/96/EC sur les déchets d'équipements électriques et électroniques (DEEE), ce produit électrique ne doit en aucun cas être mis au rebut sous forme de déchet municipal non trié. Veuillez vous débarrasser de ce produit en le renvoyant à son point de vente ou au point de ramassage local dans votre municipalité, à des fins de recyclage.

ITALIANO

Questo simbolo sui prodotto o sulla relativa confezione indica che il prodotto non va trattato come un rifiuto domestico. In ottemperanza alla Direttiva UE 2002/96/EC sui rifiuti di apparecchiature elettriche ed elettroniche (RAEEI), questa prodotto elettrico non deve essere smaltito come rifiuto municipale misto. Si prega di smaltire il prodotto riportandolo al punto vendita o al punto di raccolta municipale locale per un opportuno riciclaggio.

POLSKI

Jeśli na produkcie lub jego opakowaniu umieszczono ten symbol, wówczas w czasie utylizacji nie wolno wyrzucać tego produktu wraz z odpadami komunalnymi. Zgodnie z Dyrektywą Nr 2002/96/WE w sprawie zużytego sprzętu elektrycznego i elektronicznego (WEEE), niniejszego produktu elektrycznego nie wolno usuwać jako nie posortowanego odpadu komunalnego. Prosimy o usuniecie niniejszego produktu poprzez jego zwrot do punktu zakupu lub oddanie do miejscowego komunalnego punktu zbiórki odpadów przeznaczonych do recyklingu.

Thank you for purchasing the INTELLINET NETWORK SOLUTIONS™ Wireless 150N USB Adapter, Model 524698.

This quick install guide presents the basic steps required for setting up and operating this device. For more detailed instructions and specifications (including FCC and CE warnings and statements), refer to the user manual 1) on the CD enclosed with this product; 2) on the Web site listed below; or 3) in some cases, printed and enclosed with this product. Contact your INTELLINET NETWORK SOLUTIONS dealer with comments or questions, or visit **www.intellinet-network.com** for information on the latest software and firmware updates, related products and additional contact information.

System Requirements

- Notebook or desktop PC with Pentium 1 GHz-compatible processor or higher
- Windows 2000/XP/Vista/7
- Available Hi-Speed USB 2.0 type-A port

Package Contents

- Wireless 150N USB Adapter with detachable antenna
- USB extension cable
- Quick installation guide
- Setup CD with user manual

NOTE: Some screen images have been modified to fit the format of this guide. Screen images on all compatible operating systems are similar.

ADAPTER INSTALLATION

1. Remove the adapter's protective cap and attach the antenna to the adapter by securely screwing it onto the antenna connector.
2. With your computer on, gently insert the adapter into a USB 2.0 port. ***NOTE:*** If the adapter doesn't easily slide into the port, flip the adapter over and try again.



3. The Welcome to the Found New Hardware Wizard screen will display automatically. Click "Cancel" to continue.

Found New Hardware Wizard
Welcome to the Found New Hardware Wizard
Windows will search for current and updated software by looking on your computer, on the hardware installation CD, or on the Windows Update Web site (with your permission).
Read our privacy policy
Can Windows connect to Windows Update to search for software?
Yes, this time only
Yes, now and every time I connect a device
No, not this time
Click Next to continue.
< Back
Next >
Cancel

4. Place the included setup CD in your CD/DVD-ROM drive and run the "Setup.exe" program. When the License Agreement displays, select "I accept the terms of the license agreement" and click "Next" to continue.

5. The first of two Setup Type screens will display. If the adapter is being installed for the first time, it's recommended that you select "Install driver and INTELLINET WLAN Utility." To simply update the driver, select "Install driver only." Click "Next" to continue.


INTELLINET 802.11 WIRELESS LAN CARD - InstallShield Wizard
Setup Type
Select the setup type that best suits your needs.
Choose to install...
Install driver and INTELLINET WLAN Utility
Install driver only
InstallShield
< Back
Next >
Cancel

6. The second Setup Type screen presents two options for configuring the adapter. "INTELLINET Configuration Tool" is recommended, as it provides full access to all of the adapter's functions. If you prefer to use the wireless configuration tool provided by Windows XP or Vista, select "Microsoft Zero Configuration Tool." Click "Next."



7. When the Ready to Install the Program screen displays, click “Install.” To change any previous selections/settings, click “Back”; to exit the InstallShield Wizard, click “Cancel.” ***NOTE:*** If the Found New Hardware Wizard screen displays again, wait until the InstallShield Wizard Complete screen displays.
8. When the InstallShield Wizard Complete screen displays, click “Finish.”

WIRELESS AP CONNECTION

The configuration utility is a powerful application that helps you configure the adapter and monitor link status and statistics during the communication process.

1. Once the adapter’s installation process is complete, the icon for the wireless configuration utility will automatically appear on the computer desktop and at the lower-right corner of the system tray. Right-click the icon and select the configuration utility or switch the adapter to AP mode (refer to the user manual for details).



2. The configuration utility will scan for wireless APs and access any unencrypted wireless APs automatically. To connect to one, select/highlight it and click “Connect.” ***NOTE:*** If a wireless access point you want to connect to doesn’t appear in the AP List field, click “Rescan.”



3. If the wireless access point uses encryption, you need to input a WEP key or WPA preshared key. Obtain it from the owner of the wireless AP you want to connect to, enter it in the corresponding text field, and click “OK.” ***NOTE:*** The authentication type is selected automatically and shouldn’t be changed.



4. When a wireless access point is successfully connected, a blue pointer appears to the left of its name on the AP list.



For details about advanced settings and configuration instructions for the many additional features of the Wireless 150N USB Adapter, refer to the user manual on the included setup CD.

EINLEITUNG

Vielen Dank für den Kauf des Wireless 150N USB Adapters (Modell 524698) von INTELLINET NETWORK SOLUTIONS™.
Diese Kurzanleitung zeigt die rudimentären Schritte zur Einrichtung und Betriebnahme dieses Gerätes.
Für eine spezifische und detailiertere Anleitung können Sie
1) in dem Handbuch auf der beiliegenden CD nachlesen
2) weitere Information auf der Webseite nachsehen
3) bei einigen Produkten das beiliegende Benutzerhandbuch lesen.
Bei Fragen und Kommentare wenden Sie sich bitte an Ihren INTELLINET NETWORK SOLUTIONS Händler und besuchen Sie www.intellinet-network.com für neueste Software- und Firmware-Upgrades, sowie weiterer produktbezogener Informationen.

Lieferumfang
- Wireless 150N USB Adapter mit abnehmbarer Antenne
- USB Verlängerungskabel
- Setup CD und Handbuch

Systemvoraussetzungen
- Notebook oder PC mit Pentium 1 GHz kompatiblem Prozessor oder höher
- Windows 2000/XP/Vista/7
- Ein freier Hi-Speed USB 2.0 Port

INSTALLATION

WICHTIG: Installieren Sie zuerst die Software, bevor Sie den Wireless 150N USB Adapter anschließen. Falls Sie das doch getan haben, warten Sie bitte bis der “Neue Hardware gefunden” Bildschirm erscheint und wählen Sie dann “Abbrechen”.

1. Legen Sie die beiliegende Setup CD in das CD-ROM Laufwerk und starten Sie das Programm INTELLINET WLAN.exe. Wenn der Bilschirm mit den Lizenzvereinbarungen erscheint, wählen Sie weiter, um diese zu akzeptieren.

INTELLINET 802.11 WIRELESS LAN CARD - InstallShield Wizard
License Agreement
Please read the following license agreement carefully.
INTELLINET NETWORK SOLUTIONS Wireless Utility for Windows 2000/XP/Vista
Copyright (C) : INTELLINET NETWORK SOLUTIONS . All Rights Reserved.
Thank you for purchasing INTELLINET NETWORK SOLUTIONS Wireless product!
SOFTWARE PRODUCT LICENSE
The SOFTWARE PRODUCT is protected by copyright laws and international copyright treaties, as well as other intellectual property laws and treaties. The SOFTWARE PRODUCT is licensed, not sold.
1. GRANT OF LICENSE. This End-User License Agreement grants you the following rights:Installation and Use. You may install and use an unlimited number of copies of the SOFTWARE PRODUCT.
Reproduction and Distribution. You may reproduce and distribute an unlimited number of copies of the SOFTWARE PRODUCT; provided that each copy shall be a true and complete copy, including all copyright and trademark notices, and shall be accompanied by a copy of this EULA. Copies of the SOFTWARE PRODUCT may be distributed as a standalone product or included with your own product.
I accept the terms of the license agreement
I do not accept the terms of the license agreement
Print
InstallShield
< Back
Next >
Cancel

2. Wenn Sie den Wireless 150N USB Adapter zum ersten mal benutzen, ist zu empfehelen, sowohl Treiber, als auch die Software zu installieren. Falls Sie nur die Treiber aktualisieren wollen, wählen Sie “Install driver only”. Danach klicken Sie auf “Weiter” um fortzufahren.


INTELLINET 802.11 WIRELESS LAN CARD - InstallShield Wizard
Setup Type
Select the setup type that best suits your needs.
Choose to install...
Install driver and INTELLINET WLAN Utility
Install driver only
InstallShield
< Back
Next >
Cancel

3. Auf dem zweiten Setup-Bildschirm müssen Sie ein Konfigurations-Tool auswählen. Wählen Sie “INTELLINET Configuration Tool”, da hiermit alle Eigenschaften des Adapters unterstützt werden. Falls Sie das von Windows XP/Vista zur Verfügung gestellte Tool nutzen wollen, wählen Sie “Microsoft Zero Configuration Tool.” Klicken Sie auf “Weiter”.



4. Klicken Sie nun auf “Install.”

HINWEIS: Falls der “Neue Harware gefunden” Bildschirm erneut erscheint, warten Sie einen moment, bis diese Mitteilung erscheint.



5. Wenn der Installationsassistent mit dem Setup fertig ist, wählen Sie “Yes, I want to restart my computer now” und “Finish”, um den Rechner neu zu starten.

INTELLINET 802.11 WIRELESS LAN CARD - InstallShield Wizard
InstallShield Wizard Complete
Before you can use the program,
you must restart your computer.
Yes, I want to restart my computer now.
No, I will restart my computer later.
Remove any disks from their drives,
and then click Finish to complete setup.
INTELLINET
NETWORK SOLUTIONS
InstallShield
< Back
Finish
Cancel

6. Nachdem der Rechner neu gestartet wurde, stecken Sie den Wireless 150N USB Adapter in einen freien USB 2.0 Port.



7. Wenn der Bildschirm “Neue Hardware gefunden” erscheint, wählen Sie, “Nein, diesmal nicht” und klicken Sie auf “Weiter”.

Found New Hardware Wizard
Welcome to the Found New Hardware Wizard
Windows will search for current and updated software by looking on your computer, on the hardware installation CD, or on the Windows Update Web site (with your permission).
Read our privacy policy
Can Windows connect to Windows Update to search for software?
Yes, this time only
Yes, now and every time I connect a device
No, not this time
Click Next to continue.
< Back
Next >
Cancel

8. Wenn der Assistent fragt, wie er vorgehen soll, wählen Sie “Automatische Installation (Empfohlen)” und klicken Sie “Weiter”.


Found New Hardware Wizard
This wizard helps you install software for:
INTELLINET Wireless 150N USB Adapter
If your hardware came with an installation CD or floppy disk, insert it now.
What do you want the wizard to do?
Install the software automatically (Recommended)
Install from a list or specific location (Advanced)
Click Next to continue.
< Back
Next >
Cancel

9. Eine Status Anzeige zeigt den Fortschritt der Installation an.



10. Nach der vollständigen Installation ist Ihr Wireless 150N USB Adapter bereit, eingerichtet zu werden.

KONFIGURATION

Nach der installation können Sie den Wireless 150N USB Adapter so einrichten, daß er sich mit einem Wireless Access Point (AP) verbindet. Die Konfigurationssoftware startet automatisch und Sie finden ein rot-weißes INTELLINET Symbol in Ihrerm Windows Leiste.

1. Rechtsklicken Sie auf das INTELLINET Symbol und wählen Sie “Launch Config Utility.”



2. Die Konfigurationssoftware sucht jetzt nach Wireless Netzwerken in Reichweite. Klicken Sie auf “Rescan” um diese Liste zu aktualisieren. Um sich mit einem WLAN zu verbinden, klicken Sie darauf und wählen “Connect.”



3. Falls das Netzwerk meine Verschlüsselung nutzt, müssen Sie den richtigen Schlüssel eingeben. Die Konfigurationssoftware empfiehlt automatisch den richtigen Authentifizierungstyp (siehe Auswahl), und Sie sollten diesen Wert nicht ändern. ***HINWEIS:*** Für WPA/WPA2 müssen Sie auch den korrekten Verschlüsselungtyp wählen (AES oder TKIP). Diese Einstellungen hängen von Ihrem Wireless Netzwerk und nur der Besitzer dieses Netzwerkes kann Ihnen die erforderlichen Informationen geben.



4. Wenn Sie mit dem Access Point verbunden sind, erscheint ein ▶ vor dem Namen des Gerätes.



HINWEIS: Für weitere Einstellungen und Eigenschaften des Wireless 150 N USB Adapters, lesen Sie bitte das Handbuch auf der beiliegenden CD.

INTELLINET NETWORK SOLUTIONS™ offers a complete line
of active and passive networking products.
Ask your local computer dealer for more information or visit
www.intellinet-network.com.

I INTELL INET NETWORK SOL UTIONS™ bietet ein komplettes Portfolio
aktiverund passiver Netzwerkkomponenten.
Für weitere Informationen wenden Sie sich bitte an Ihren Händler oder
besuch en Sie
www.intellinet-network.com

Copyright © INTELLINET NETWORK SOLUTIONS
All products mentioned are trademarks or registered trademarks of their respective owners.